




## Coordinator and base system

**Industrial engines**  
**DC09, DC13, DC16**

**Marine engines**  
**DI09, DI13, DI16**



339 182





|   |           |
|---|-----------|
| <b>Introduction .....</b>                       | <b>3</b>  |
| Different requirements .....                    | 3         |
| Without Scania's base system.....               | 3         |
| With Scania's base system.....                  | 3         |
| Grounding.....                                  | 4         |
| Abbreviations .....                             | 4         |
| <b>Coordinator.....</b>                         | <b>5</b>  |
| Operating voltage .....                         | 5         |
| Protection class.....                           | 5         |
| Vibration levels .....                          | 5         |
| Fitting the coordinator .....                   | 6         |
| Connection to coordinator .....                 | 7         |
| Coolant temperature gauge configuration .....   | 8         |
| Oil pressure gauge configuration .....          | 8         |
| Single-speed engines .....                      | 9         |
| Industrial engines .....                        | 18        |
| Marine engines .....                            | 22        |
| <b>Base system for industrial engines .....</b> | <b>26</b> |
| Connection to main junction box .....           | 28        |
| Connection to coordinator junction box .....    | 32        |
| <b>Base system for marine engines .....</b>     | <b>40</b> |
| Connection to main junction box .....           | 42        |
| Connection to coordinator junction box .....    | 45        |
| <b>Extra functions .....</b>                    | <b>46</b> |
| Industrial and marine engines .....             | 46        |
| Industrial engines only .....                   | 48        |





## Introduction

### Different requirements

S6 engine management system is used for PDE engines. S8 engine management system is used for XPI engines.

There are two different conditions for the electrical installation of S6 and S8: with or without Scania's base system. This installation manual describes Scania's coordinator and base system only. All other information about the electrical installation can be found in 03:01 Electrical systems.

### Without Scania's base system

#### Engine only

All electrical connections by Scania are carried out to the engine control unit. The customer is responsible for the electrical system otherwise.

#### With a coordinator

The engine can be ordered with or without a coordinator.

The task of the coordinator is to convert the CAN signals from the engine control unit to analogue signals.

In addition to the engine control unit, indicator lamps, switches, controls and other equipment related to the engine are connected to the coordinator.

### With Scania's base system

The engine is supplied with a plug and play base system. It is easy to connect the system, and no major adaptations are required. The base system is not classified.





## Grounding

In this document the term ground is used. Ground means that there is a connection to the battery negative terminal (U31).

## Abbreviations

Abbreviations used in this document are listed in the table below.

| Abbreviation | Explanation   |
|--------------|---|
| PDE          | Fuel injection system (unit injector)                   |
| S6           | Engine control unit for PDE engines                     |
| S8           | Engine control unit for XPI engines                     |
| SCR          | Emission control system (Selective Catalytic Reduction) |
| SDP3         | Scania Diagnos & Programmer 3                           |
| XPI          | Fuel injection system (extra high pressure injection)   |

## Abbreviations for voltage

The abbreviations in the table below are used to describe different types of voltage. Unless otherwise specified, always +24 V.

| Abbreviation | Explanation                      |
|--------------|----------------------------------|
| U15          | Starter key voltage (15 voltage) |
| U30          | Battery voltage                  |
| U50          | Voltage to the starter motor     |





## Coordinator

### Operating voltage

For the coordinator to function according to specification, the voltage must be 22-30 V. The normal voltage is 28 V.

### Protection class

The coordinator has IP class 5K4.

### Vibration levels

The driver's cab is an example of a suitable location to place the coordinator.

The coordinator withstands the following vibration levels:

| ASD level               | Frequency range | RMS level      |
|-------------------------|-----------------|----------------|
| 0.05g <sup>2</sup> /Hz  | 10-50 Hz        | In total 3.2 g |
| 0.015g <sup>2</sup> /Hz | 100-500 Hz      |                |





## Fitting the coordinator




### IMPORTANT!

Protect the coordinator against impact from the environment. Position the coordinator with the electrical cables downwards as illustrated to minimise the risk of moisture and water entering the electrical cable.

The following factors can cause electronic components to malfunction:

- Electromagnetic interference
- Extreme heat or cold
- High voltages
- Vibrations
- Water and moisture



*Location of the coordinator*





## Connection to coordinator


Contact housing kit 1 505 750 for coordinator contains the following parts:

| Qty | Part No.  | Designation                 |
|-----|-----------|-----------------------------|
| 1   | 1 404 305 | Contact housing, 70-pin     |
| 4   | 815 886   | Cable terminal, flat socket |
| 30  | 816 054   | Cable terminal, flat socket |
| 1   | 815 361   | Cable ties, 185 x 4.6 mm    |
| 1   |           | Resistor, 665 ohms          |

Use the following tools for contact housing kit 1 505 750:

- Hand crimping tool 99 491.
- Dismantling tools 588 219 and 99 585.

Use electrical cables which are twisted 40 turns per metre when connecting an accelerator pedal to an all-speed engine and a potentiometer for engine speed setting to a single-speed engine.



*Connector for coordinator*

339 191





## Coolant temperature gauge configuration

If Scania's base system is not used, the following coolant temperature output parameters should be set:

Temperature gauge calibration X: can be set between -40 and +140°C in increments of 1°C.

Temperature gauge calibration Y: can be set between 0 and 100% operating cycle in increments of 0.1%.

|          |      |      |      |      |      |      |     |    |
|----------|------|------|------|------|------|------|-----|----|
| <b>X</b> | 40   | 70   | 80   | 90   | 100  | 110  | 120 | °C |
| <b>Y</b> | 55.3 | 32.9 | 26.6 | 21.1 | 16.1 | 12.1 | 9.0 | %  |



## Oil pressure gauge configuration

If Scania's base system is not used, the following oil pressure output parameters should be set:

Oil pressure gauge calibration X: can be set between 0 and 10 bar in increments of 0.1 bar.

Oil pressure gauge calibration Y: can be set between 0 and 100% operating cycle in increments of 0.1%.

|          |      |      |      |      |      |      |      |     |
|----------|------|------|------|------|------|------|------|-----|
| <b>X</b> | 0    | 1.0  | 2.0  | 4.0  | 6.0  | 8.0  | 10.0 | bar |
| <b>Y</b> | 10.0 | 23.8 | 31.3 | 43.1 | 50.3 | 54.5 | 59.4 | %   |








## Coordinator inputs and outputs



## IMPORTANT!

To prevent the engine control unit from generating fault codes, the following pins in the coordinator must be connected:

- 1  
7  
21  
29  
32  
45  
48  
49







| Pin | I/O | Function  | Description  | Comments  |
|-----|-----|---|--|---|
| 1   | -   | Ground  | Ground for coordinator.  |   |
| 4   | O   | Warning lamp for alternator                     | Lights in the event of an alternator fault.  | A CAN message is sent to the coordinator if an alternator does not charge correctly. The coordinator then sends out +24 V and the warning lamp lights. Note: The lamp must be a bulb.   |
| 5   | O   | Buzzer  | Signal in the event of an engine alarm.  | The coordinator sends out +24 V in the event of an engine alarm.  |
| 6   | O   | Warning lamp for coolant temperature            | Lights when the coolant temperature is too high.   | The coordinator sends out ground if the coolant temperature is too high. Note: The lamp must be a bulb.   |
| 7   | I   | Drive position                                  | Starter key in the drive position.   | Should be connected to U15 when it is active.   |
| 9   | O/I | Warning lamp for low coolant level or lamp test | The pin has two different functions: <ul style="list-style-type: none"><li>• To light an indicator lamp when the coolant level is too low.</li><li>• To carry out a lamp test.</li></ul> | The coolant level monitor is connected to the engine control unit. When the coolant level is too low, the coordinator sends out ground on the pin and the warning lamp lights. If the pin is connected to ground, a lamp test is carried out on pins 4, 5, 6, 15, 9 and 12. The lamp test is active as long as pin 9 is connected to ground. Note: The lamp must be a bulb. |
| 10  | O   | Gauge for coolant temperature                   | Gauge displaying the engine coolant temperature.   | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal. See the section Configuring coolant temperature gauge.  |
| 11  | O   | Gauge for oil pressure                          | Gauge displaying the engine oil pressure.  | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal. See the section Configuring oil pressure gauge.   |
| 12  | O/I | Diagnostics lamp                                | Shows if there is an active fault code for the coordinator or engine control unit.   |   |
| 13  | I   | Switch 1 for nominal engine speed               | Switch to change the fixed engine speed which the engine is set to.  | The nominal engine speed can be changed by connecting pin 13 and 36 to ground in different combinations. See section Change in nominal engine speed.  |
| 15  | O   | Warning lamp for low oil pressure               | Lights when oil pressure is too low.   | Ground is sent out from this pin when the oil pressure is too low. Note: The lamp must be a bulb.   |
| 18  | O   | Gauge for engine speed                          | Scania's gauge for engine speed.   | If pin 46 is activated, the droop value is shown on the instrument instead. See the Droop translation table in the Droop or isochronous section.  |





| Pin | I/O | Function                                | Description  | Comments   |
|-----|-----|---|--|--|
| 21  | -   | CAN low                                 |  |  |
| 24  | -   | Fine adjustment of nominal engine speed | Zero potential from coordinator for the signal for adjustment of nominal engine speed.                           | This pin is the zero potential 0 V for the potentiometer for adjustment of the engine speed around the pre-set engine speed. More information is available in the section Fine adjustment of nominal engine speed.                                     |
| 28  | -   | Fine adjustment of nominal engine speed | Supply voltage from coordinator for the signal for adjustment of nominal engine speed.                           | This pin is the voltage potential 5 V for the potentiometer for adjustment of the engine speed around the pre-set engine speed. More information is available in the section Fine adjustment of nominal engine speed.                                  |
| 29  | -   | Governor function                       | Connection of resistor as per figure creates a stiff or soft governor function. Used in combination with pin 48. | If no resistor net is connected, the standard governor.  |
| 30  | I   | Droop or isochronous                    | Switching between droop and isochronous engine speed.  | If the pin is not connected, the engine can be run with droop. See pin 46 for droop adjustment. If the pin is connected to ground, isochronous operation is possible.  |
| 32  | I   | Engine start (U50)                      | Engine start via CAN.  | The engine is started by connecting the pin to +24 V.  |
| 34  | I   | Engine speed or torque control          | Control of engine speed or engine torque.  | The function makes it possible to control torque instead of engine speed. The engine default is engine speed control. To control torque, the pin should be connected to ground.  |
| 36  | I   | Switch 2 for nominal engine speed       | Switch to change the fixed engine speed which the engine is set to.  | The nominal engine speed can be changed by connecting pin 13 and 36 to ground in different combinations. See section Change in nominal engine speed.   |
| 40  | I   | Torque limit switch 2                   | Used together with torque limit switch 1 to select a preset torque curve.  | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.   |
| 45  | -   | CAN high                                |  |  |
| 46  | I   | Droop adjustment                        | Adjusting the droop value.   | If the pin is connected to +24 V the droop value can be adjusted via pin 52 and 53 on the coordinator. The current droop value is displayed on the engine speed gauge. See pin 18 and the Droop translation table in the Droop or isochronous section. |
| 48  | -   | Ground for the governor function        | See pin 29.  |  |
| 49  | -   | Battery voltage                         | Battery voltage for the coordinator.   | The pin should be connected to U30.  |





| Pin | I/O | Function  | Description   | Comments  |
|-----|-----|---|---|---|
| 50  | I   | Buzzer off                                      | Disconnecting buzzer.   | If the pin is connected to ground, the connected buzzer is switched off. The coordinator does not send out a signal on pin 5.   |
| 51  | I   | Engine shutdown                                 | Shutting down the engine.   | To stop the engine, the pin should be connected to ground. The engine can also be shut down via the starter lock by disconnecting U15.  |
| 52  | I   | Droop decrease                                  | Decrease in the droop value.  | More information is available in the Droop or isochronous section.  |
| 53  | I   | Droop increase                                  | Increase in the droop value.  | More information is available in the Droop or isochronous section.  |
| 54  | I   | Fine adjustment of nominal engine speed         | Fine adjustment of engine speed around the selected nominal engine speed (output signal 5 V).   | <ul style="list-style-type: none"><li>• 0.45-3 V equivalent to 0-100%</li><li>• 0% equivalent to -120 rpm</li><li>• 100 % equivalent to +120 rpm</li></ul> Between these two, the value changes linearly. The limit values are 0-0.25 V and 4-5 V. If a value is within these intervals, a fault code is generated. |
| 57  | I   | Disengaging engine shutdown                     | If the function is active, the engine continues to run even if a fault code is generated which specifies that the engine should stop due to safety reasons. | The function is activated by connecting the pin to U15. An information code is generated which shows that the function is activated. The engine control unit must be programmed for the function.   |
| 60  | I   | Torque limit switch 1                           | Used together with torque limit switch 2 to select a preset torque curve.   | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.  |
| 61  | I   | Reading flash codes for the engine control unit |   | Not used.   |





## Change in nominal engine speed

It is possible to change the nominal engine speed set at the factory.

There are 4 alternatives to choose from. The different alternatives are selected by changing pins 13 and 36 on the coordinator in different combinations.

The following combinations are possible:

| Value           | Pin 13        | Pin 36        |
|-----------------|---------------|---------------|
| Factory default | Not connected | Not connected |
| 1,500 rpm       | Ground        | Not connected |
| 1,800 rpm       | Not connected | Ground        |
| Idling speed    | Ground        | Ground        |

## Fine adjustment of nominal engine speed

The coordinator has a function for fine adjustment of nominal engine speed. This can be used to adjust the engine speed with  $\pm 120$  rpm. If you wish to use this function, it must be specified when ordering. For fine adjustment of the nominal engine speed, a potentiometer is connected to coordinator pins 24, 28 and 54.

Examples of fine adjustment of nominal engine speed with potentiometer:

$54\% = (3.0 - 0.45) \times 0.54 + 0.45 = 1.827 \text{ V} \Rightarrow$  engine speed adjusted by +10 rpm.

Without droop =  $1,500 + 10 = 1,510$  rpm.

With droop 4% =  $1,500 + (0.04 \times 1,500) + 10 = 1,570$  rpm.

The adjustment range can be changed with SDP3.






The coordinator has a basic setting so that 0.45-2.97 V corresponds to 0-100% on the potentiometer.

0% equivalent to -120 rpm

100% corresponds to +120 rpm, with a linear change.

Example: 50% (1.725 V) on the potentiometer corresponds to 0 rpm adjustment.

The limit values outside of the adjustment range are 0-0.25 V and 4.0-5.0 V. If a value is within these ranges, a fault code is generated and the engine runs at nominal speed.



If no potentiometer is installed and the coordinator is programmed for one, a fault code will be generated and the engine will run at nominal engine speed.

To achieve nominal engine speed without potentiometer and without fault code generation, a resistor (R1) must be connected between coordinator pins 28 and 54 and another resistor (R2) must be connected between coordinator pins 24 and 54.

The ratio between R1 and R2 should be

$$R1 = 2.15 \times R2.$$

Scania recommends

$$R1 = 1,000 \text{ ohms and } R2 = 470 \text{ ohms.}$$

Using SDP3, it is possible to set whether the coordinator should receive a potentiometer signal or not.





## Droop or isochronous

In order to obtain a more dynamic system, the engine can be run with droop engine speed increase.

Isochronous engine speed increase means that the engine is operated with 0% droop.

In order to run the engine with droop, pin 30 of the coordinator must not be connected (default setting).

For isochronous engine running, connect pin 30 of the coordinator to ground.

Droop is calculated for full load (100%).

The default value for droop is 4%, but this can be changed from 0 to 20% with SDP3. Contact the supplier for assistance.

The droop value can be changed directly on the coordinator as follows:

1. Activate pin 46 (droop adjustment) by connecting it to U30.
2. Increase the value: Connect pin 52 to and from ground. Each connection increases the droop value by 0.1%.
3. Decrease the value: Connect pin 53 to and from ground. Each connection decreases the droop value by 0.1%.
4. The current droop value can be read from the engine speed gauge (pin 18) when pin 46 is not connected. See the Droop translation table on the next page.
5. Save the set droop value by disconnecting pin 46.





## Droop translation table

Read the droop value on the engine speed gauge using the translation table below.

If a frequency gauge is connected to pin 18, the table can be used to read the droop value as a frequency instead.

| Droop (%) | Engine speed (rpm) | Frequency (Hz) |
|-----------|--------------------|----------------|
| 0.0       | 00                 | 0              |
| 0.1       | 50                 | 17             |
| 0.2       | 100                | 34             |
| 0.3       | 150                | 52             |
| 0.4       | 200                | 69             |
| 0.5       | 250                | 86             |
| 0.6       | 300                | 104            |
| 0.7       | 350                | 121            |
| 0.8       | 400                | 139            |
| 0.9       | 450                | 156            |
| 1.0       | 500                | 173            |
| 1.1       | 550                | 191            |
| 1.2       | 600                | 208            |
| 1.3       | 650                | 226            |
| 1.4       | 700                | 243            |
| 1.5       | 750                | 260            |
| 1.6       | 800                | 278            |

| Droop (%) | Engine speed (rpm) | Frequency (Hz) |
|-----------|--------------------|----------------|
| 1.7       | 850                | 295            |
| 1.8       | 900                | 313            |
| 1.9       | 950                | 330            |
| 2.0       | 1,000              | 347            |
| 2.1       | 1,050              | 365            |
| 2.2       | 1,100              | 382            |
| 2.3       | 1,150              | 400            |
| 2.4       | 1,200              | 417            |
| 2.5       | 1,250              | 434            |
| 2.6       | 1,300              | 452            |
| 2.7       | 1,350              | 469            |
| 2.8       | 1,400              | 486            |
| 2.9       | 1,450              | 504            |
| 3.0       | 1,500              | 521            |
| 3.1       | 1,550              | 539            |
| 3.2       | 1,600              | 556            |
| 3.3       | 1,650              | 573            |





| Droop (%) | Engine speed (rpm) | Frequency (Hz) |
|-----------|--------------------|----------------|
| 3.4       | 1,700              | 591            |
| 3.5       | 1,750              | 608            |
| 3.6       | 1,800              | 626            |
| 3.7       | 1,850              | 643            |
| 3.8       | 1,900              | 660            |
| 3.9       | 1,950              | 678            |
| 4.0       | 2,000              | 695            |
| 4.1       | 2,050              | 713            |
| 4.2       | 2,100              | 730            |
| 4.3       | 2,150              | 747            |
| 4.4       | 2,200              | 765            |
| 4.5       | 2,250              | 782            |
| 4.6       | 2,300              | 800            |
| 4.7       | 2,350              | 817            |

| Droop (%) | Engine speed (rpm) | Frequency (Hz) |
|-----------|--------------------|----------------|
| 4.8       | 2,400              | 834            |
| 4.9       | 2,450              | 852            |
| 5.0       | 2,500              | 869            |
| 5.1       | 2,550              | 886            |
| 5.2       | 2,600              | 904            |
| 5.3       | 2,650              | 921            |
| 5.4       | 2,700              | 939            |
| 5.5       | 2,750              | 956            |
| 5.6       | 2,800              | 973            |
| 5.7       | 2,850              | 991            |
| 5.8       | 2,900              | 1,008          |
| 5.9       | 2,950              | 1,026          |
| 6.0       | 3,000              | 1,043          |

## Torque and engine speed control

If pin 34 of the coordinator is connected to ground, the system begins to regulate the torque instead of the engine speed.

The user can now set the load from 0 to 100% with the potentiometer, i.e. from idling to full load with coordinator pins 24, 28 and 54.

Engine speed must then be regulated by an external network. If pin 34 on the coordinator is not connected, the user regulates the engine speed.





## Industrial engines

### Coordinator inputs and outputs


The illustration shows a schematic description of the coordinator inputs and outputs (I/O).



#### IMPORTANT!

To prevent the engine control unit from generating fault codes, the following pins in the coordinator must be connected:

1  
7  
21  
24  
29  
32  
45  
48  
49  
52  
54







| Pin | I/O | Function  | Description  | Comments  |
|-----|-----|---|--|---|
| 1   | -   | Ground  | Ground for coordinator.  |   |
| 4   | O   | Warning lamp for alternator                     | Lights in the event of an alternator fault.  | A CAN message is sent to the coordinator if an alternator does not charge correctly. The coordinator then sends out +24 V and the warning lamp lights. Note: The lamp must be a bulb.   |
| 5   | O   | Buzzer  | Signal in the event of an engine alarm.  | The coordinator sends out +24 V in the event of an engine alarm.  |
| 6   | O   | Warning lamp for coolant temperature            | Lights when the coolant temperature is too high.   | The coordinator sends out ground if the coolant temperature is too high. Note: The lamp must be a bulb.   |
| 7   | I   | Drive position                                  | Starter key in the drive position.   | Should be connected to U15 when it is active.   |
| 8   | I   | Cruise control off                              | Disconnects speed adjustment functions.  | Connected to U30 to deactivate selected speed adjustment function.  |
| 9   | O/I | Warning lamp for low coolant level or lamp test | The pin has two different functions: <ul style="list-style-type: none"><li>• To light an indicator lamp when the coolant level is too low.</li><li>• To carry out a lamp test.</li></ul> | The coolant level monitor is connected to the engine control unit. When the coolant level is too low, the coordinator sends out ground on the pin and the warning lamp lights. If the pin is connected to ground, a lamp test is carried out on pins 4, 5, 6, 15, 9 and 12. The lamp test is active as long as pin 9 is connected to ground. Note: The lamp must be a bulb. |
| 10  | O   | Gauge for coolant temperature                   | Gauge displaying the engine coolant temperature.   | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal. See the section Configuring coolant temperature gauge.  |
| 11  | O   | Gauge for oil pressure                          | Gauge displaying the engine oil pressure.  | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal. See the section Configuring oil pressure gauge.   |
| 12  | O/I | Diagnostics lamp                                | Shows if there is an active fault code for the coordinator or engine control unit.   |   |
| 13  | I   | Engine speed setting 1                          |  | The function is activated by connecting the pin to ground. More information is available in the sections Engine speed setting 1 and 2.  |
| 15  | O   | Warning lamp for low oil pressure               | Lights when oil pressure is too low.   | Ground is sent out from this pin when the oil pressure is too low. Note: The lamp must be a bulb.   |
| 18  | O   | Gauge for engine speed                          | Scania's gauge for engine speed.   | Frequency X 2.88 gives the engine speed.  |
| 21  | -   | CAN low   |  |   |





| Pin | I/O | Function                     | Description   | Comments   |
|-----|-----|------------------------------|---|--|
| 24  | -   | Ground for accelerator pedal | Connected directly to the coordinator.  | Must not be connected to battery ground.   |
| 28  | -   | Supply to accelerator pedal  | +5 V directly from the coordinator.   |  |
| 29  | I   | Adjust 1                     | Used in combination with pin 48 to set the engine speed.  | <ul style="list-style-type: none"><li>• To activate, 665 ohms between pin 29 and 48.</li><li>• To deactivate, 1,596 ohms between pin 29 and 48.</li><li>• To increase, 61 ohms between pin 29 and 48.</li><li>• To save, 154 ohms between pin 29 and 48.</li><li>• To reduce, 332 ohms between pin 29 and 48.</li></ul>  |
| 30  | I   | Idling switch                | Signals to the coordinator that the accelerator pedal is fully functional.                              | The function is activated by connecting the pin to ground. If the function should be deactivated, the pin must not be connected. It should be activated when the throttle signal is in the range 0.4-20%. If it is not activated between the set values, a fault code is generated and the throttle control stops to function.   |
| 32  | I   | Engine start (U50)           | Engine start via CAN.   | Connect the pin to +24 V to start the engine.  |
| 34  | I   | Kickdown signal              | Signals to the coordinator that the accelerator pedal is fully depressed. The function must be ordered. | <p>The function is activated by connecting the pin to ground. It is activated or is deactivated over 3 V and under 4 V. The function does not need to be engaged. The only requirement is that the throttle is at 100% if it is to be activated.</p> <p>If the function is activated before the throttle is at 100%, a fault code is generated but the throttle control is functioning. The function must be activated when the throttle control is at 100% in order to get a temporary power increase. No fault code is generated if the function is deactivated.</p> |
| 36  | I   | Engine speed setting 2       |   | See pin 13.  |
| 40  | I   | Torque limit switch 2        | Used together with torque limit switch 1 to select a preset torque curve.                               | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.   |
| 41  | I   | Vehicle speed                |   | Not used.  |
| 45  | -   | CAN high                     |   |  |
| 46  | I   | Exhaust brake                | Activated by connecting to U30.   | The engine should have an electrically controlled exhaust brake, and the function should be activated with SDP3.   |





| Pin | I/O | Function  | Description   | Comments  |
|-----|-----|---|---|---|
| 48  | I   | Adjust 2  | See pin 29.   |   |
| 49  | -   | Battery voltage                                 | Battery voltage for the coordinator.  | The pin should be connected to U30.   |
| 50  | I   | Buzzer off                                      | Disconnecting buzzer.   | If this pin is connected to ground, the connected buzzer is switched off. The coordinator does not send out a signal on pin 5.  |
| 51  | I   | Engine shutdown                                 | Shutting down the engine.   | To stop the engine, the pin should be connected to ground. The engine can also be shut down via the starter lock by disconnecting U15.  |
| 52  | I   | Low idle speed adjustment 1                     | Connected to ground.  | When the brake pedal is activated, both pins should be in alternate positions, i.e. pin 4 should be connected to ground and pin 5 should remain disconnected. These 2 pins work together for safety reasons, and should be in alternate positions all the time. |
| 53  | I   | Low idle speed adjustment 2                     | Not connected.  |   |
| 54  | I   | Accelerator pedal signal                        | Signal from the throttle control to the coordinator.  | The basic value for signal level is $0.45-3 \text{ V}^1 \Rightarrow 0-100\%$ . The signal level 0-100% can be set using SDP3.   |
| 57  | I   | Disengaging engine shutdown                     | If the function is active, the engine continues to run even if a fault code is generated which specifies that the engine should stop due to safety reasons. | The function is activated by connecting the pin to U15. An information code is generated which shows that the function is activated. The engine control unit must be programmed for the function.   |
| 60  | I   | Torque limit switch 1                           | Used together with torque limit switch 2 to select a preset torque curve.   | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.  |
| 61  | I   | Reading flash codes for the engine control unit |   | Not used.   |

1. For PDE engines, 0.485-2.693 V applies.





## Marine engines

### Coordinator inputs and outputs


The illustration shows a schematic description of the coordinator inputs and outputs (I/O).



#### IMPORTANT!

To prevent the engine control unit from generating fault codes, the following pins in the coordinator must be connected:

1  
7  
21  
24  
29  
32  
45  
48  
49  
52  
54



339 197





| Pin | I/O | Function  | Description   | Comments  |
|-----|-----|---|---|---|
| 1   | -   | Ground  | Ground for coordinator.   |   |
| 4   | O   | Warning lamp for alternator                     | Lights in the event of an alternator fault.   | A CAN message is sent to the coordinator if an alternator does not charge correctly. The coordinator then sends out +24 V and the warning lamp lights. Note: The lamp must be a bulb.   |
| 5   | O   | Buzzer  | Signal in the event of an engine alarm.   | The coordinator sends out +24 V in the event of an engine alarm.  |
| 6   | O   | Warning lamp for coolant temperature            | Lights when the coolant temperature is too high.  | The coordinator sends out ground if the coolant temperature is too high. Note: The lamp must be a bulb.   |
| 7   | I   | Drive position                                  | Starter key in the drive position.  | Should be connected to U15 when it is active.   |
| 8   | I   | Remote engine start                             | Starts the engine remotely.   | When the pin is connected to +24 V, the starter motor runs and the engine only runs at idling.  |
| 9   | O/I | Warning lamp for low coolant level or lamp test | The pin has two different functions: <ul style="list-style-type: none"> <li>To light an indicator lamp when the coolant level is too low.</li> <li>To carry out a lamp test.</li> </ul> | The coolant level monitor is connected to the engine control unit. When the coolant level is too low, the coordinator sends out ground on the pin and the warning lamp lights. If the pin is connected to ground, a lamp test is carried out on pins 4, 5, 6, 15, 9 and 12. The lamp test is active as long as pin 9 is connected to ground. Note: The lamp must be a bulb. |
| 10  | O   | Gauge for engine temperature                    | Pulse width modulated (PWM) signal which is a function of the engine temperature.   | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal.   |
| 11  | O   | Gauge for oil pressure                          | Gauge displaying the engine oil pressure.   | If a Scania instrument is not used, an instrument should be used which can be configured with the PWM signal. See the section Configuring oil pressure gauge.   |
| 12  | O/I | Diagnostics lamp                                | Shows if there is an active fault code for the coordinator or engine control unit.  |   |
| 13  | I   | Fixed engine speed 1                            | Use of a fixed engine speed between low and high idling.  | The function is activated by connecting the pin to ground via a spring-loaded switch.   |
| 15  | O   | Warning lamp for low oil pressure               | Lights when oil pressure is too low.  | Ground is sent out from this pin when the oil pressure is too low. Note: The lamp must be a bulb.   |
| 18  | O   | Gauge for engine speed                          | Scania's gauge for engine speed.  | Frequency x 2.88 = the engine speed.  |





| Pin | I/O | Function                     | Description  | Comments  |
|-----|-----|------------------------------|--|---|
| 21  | -   | CAN low                      |  |   |
| 24  | -   | Ground for accelerator pedal | Connected directly to the coordinator.                                     | Must not be connected to battery ground.  |
| 28  | -   | Supply to accelerator pedal  | +5 V directly from the coordinator.  |   |
| 29  | I   | Adjust 1                     | Used in combination with pin 48 to set the engine speed.                   | <ul style="list-style-type: none"><li>• To activate, 665 ohms between pin 29 and 48.</li><li>• To deactivate, 1,596 ohms between pin 29 and 48.</li><li>• To increase, 61 ohms between pin 29 and 48.</li><li>• To save, 154 ohms between pin 29 and 48.</li><li>• To reduce, 332 ohms between pin 29 and 48.</li></ul>               |
| 30  | I   | Idling switch                | Signals to the coordinator that the accelerator pedal is fully functional. | The function is activated by connecting the pin to ground. If the function should be deactivated, the pin must not be connected.<br><br>It should be activated when the throttle signal is in the range 0.4-20%. If it is not activated between the set values, a fault code is generated and the throttle control stops to function. |
| 32  | I   | Engine start (U50)           | Engine start via CAN.  | The engine is started by connecting the pin to +24 V.   |
| 34  | I   | Temporary surplus gas        |  | Not used.   |
| 36  | I   | Fixed engine speed 2         | Use of a fixed engine speed between low and high idling.                   | The function is activated by connecting the pin to ground via a spring-loaded switch.   |
| 40  | I   | Torque limit switch 2        | Used together with torque limit switch 1 to select a preset torque curve.  | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.  |
| 41  | I   | Vehicle speed                |  | Not used.   |
| 45  | -   | CAN high                     |  |   |
| 46  | I   | Active control panel         |  | Not used.   |
| 48  | I   | Adjust 2                     | See pin 29.  |   |
| 49  | -   | Battery voltage              | Battery voltage for the coordinator.                                       | The pin should be connected to U30.   |
| 50  | I   | Buzzer off                   | Disconnecting buzzer.  | If this pin is connected to ground, the connected buzzer is switched off. The coordinator does not send out a signal on pin 5.  |





| Pin | I/O | Function  | Description   | Comments  |
|-----|-----|---|---|---|
| 51  | I   | Engine shutdown                                 | Shutting down the engine.   | To stop the engine, the pin should be connected to ground. The engine can also be shut down via the starter lock by disconnecting U15.  |
| 52  | I   | Remote control lock 2                           | Blocks operation from positions other than the remote control.  | When the pin is connected to ground, the engine cannot be run from the normal position.   |
| 53  | I   | Remote control lock 1                           | Blocks operation from positions other than the remote control.  | When the pin is connected to ground, the engine cannot be run from the normal position.   |
| 54  | I   | Accelerator pedal signal                        | The signal from the throttle control to the coordinator.  | The basic value for signal level is 0.485-2.693 V => 0-100%. The signal level 0-100% can be set using SDP3.   |
| 57  | I   | Disengaging engine shutdown                     | If the function is active, the engine continues to run even if a fault code is generated which specifies that the engine should stop due to safety reasons. | The function is activated by connecting the pin to U15. An information code is generated which shows that the function is activated. The engine control unit must be programmed for the function. |
| 60  | I   | Torque limit switch 1                           | Used together with torque limit switch 2 to select a preset torque curve.   | It is also possible to program two power curves with SDP3. There is a description of how to ground pin 40 and 60 in the Torque limitation section.  |
| 61  | I   | Reading flash codes for the engine control unit |   | Not used.   |






## Base system for industrial engines

The base system is easy to connect without any major adaptations.

It can be supplemented with an accelerator pedal sensor, analogue instrument panel, control panel with key switch and digital display. All these accessories are connected and are ready for immediate use.

Other units can also be connected via the CAN network.



*Base system for industrial engines*


- 1. Engine control unit*
- 2. Main junction box*
- 3. Coordinator junction box*
- 4. Coordinator*





A base system for industrial engines is shown here with Scania units connected.

All connectors on the main junction box and the coordinator junction box are listed on the following pages. The functions of the connectors are also described here. The purpose is to show how an electrical system other than Scania's is connected.



*Base system for industrial engines with Scania units connected*

- 1. Engine control unit
- 2. Main junction box
- 3. Connection cable: 2, 8, 12 or 24 m
- 4. Coordinator junction box
- 5. Extension cable: 2 or 8 m
- 6. Accelerator pedal sensor
- 7. Extension cable: 2 m
- 8. Scania digital display
- 9. Coordinator
- 10. Control panel
- 11. Analogue instrument panel





## Connection to main junction box


The main junction box is located between the engine control unit on the engine and the rest of the system.

It has four connectors for connecting other items to the external electrical system.


## Fuses

The main junction box has 3 or 6 fuses depending on engine emission class. The fuses are positioned next to each other along one of the long sides of the junction block.

| Emission class            | Designation | Description  |
|---------------------------|-------------|--|
| All                       | F4001       | Miniature circuit breaker of 20 A for U30 to the engine control unit.            |
|                           | F4002       | Miniature circuit breaker of 20 A for U30 to the engine control unit.            |
|                           | F4003       | Miniature circuit breaker of 8 A for U30 to the instruments.                     |
| Stage IV/<br>Tier 4f only | F4014       | Miniature circuit breaker of 20 A for U30 to the variable geometry turbocharger. |
|                           | F4015       | Miniature circuit breaker of 20 A for U30 to the SCR system.                     |
|                           | F4016       | Miniature circuit breaker of 20 A for U15 to the exhaust brake actuator.         |



Main junction box



1. Main junction box for Stage IV/Tier 4f
2. Main junction box for Stage III B/Tier 4i and less restrictive emission laws





## Connector C4028 for CAN connection

Diagnostic socket for connecting e.g. SDP3 and CAN communication. Use connector 1 508 055.


### Note:

Any equipment connected to the connector must comply with the CAN specification.

| Pin | I/O | Function | Description   |
|-----|-----|----------|---|
| 1   | -   | U15      | +24 V after fuse F4005 and relay in the junction box. Controlled by the starter lock. |
| 2   | -   | Ground   |   |
| 3   | -   | CAN high |   |
| 4   | -   | CAN low  |   |

Use the following tools for connector 1 508 055:

- Hand crimping tool 99 494.
- Dismantling tool 99 581.







## Connector C4023 for engine running signal

Connector for signal that the engine is running. When the engine is running, +24 V is sent out to pin 2. Use connector 1 508 055.


| Pin | I/O | Function              | Description  |
|-----|-----|-----------------------|--|
| 1   | -   | -                     | Not used.  |
| 2   | O   | Engine operating mode | The pin receives +24 V from the engine control unit when the engine has started. |
| 3   | -   | Ground                |  |
| 4   | -   | -                     | Not used.  |

Use the following tools for connector 1 508 055:


- Hand crimping tool 99 494.
- Dismantling tool 99 581.

## Connector C4024 for junction box

Connector for electrical cable to junction box.



*Note: For engines certified according to Stage III B/Tier 4i and less restrictive emission laws, C4023 is located next to the fuses on one of the long sides of the main junction box.*







## Connector C4027 for connecting emergency stop

Connector for connecting an emergency stop. The emergency stop disconnects the voltage to the engine control unit.

| Pin | I/O | Function | Description                   |
|-----|-----|----------|-------------------------------|
| 1   | -   | U30      | Battery voltage               |
| 2   | -   | U30      | Supply to engine control unit |
| 3   | -   | U30      | Battery voltage               |
| 4   | -   | U30      | Supply to engine control unit |


Remove the plug in the connector. Then use connector 1 845 823, which is supplied with the engine.

Use the following tools for connector 1 845 823:

- Hand crimping tool 588 206.
- Dismantling tool 99 591.

Then connect pin 1 and 3 to a switch. Route the cables back to pin 2 and 4 in connector C4027.

Now it is possible to break the main power circuit. If an emergency situation arises and the engine must be stopped quickly, this switch can be used. If the power to the system is cut 10<sup>1</sup> times in a row in this way, a fault code is generated which indicates that the engine has been stopped incorrectly.



339 217

1. Adjustable parameter.





## Connection to coordinator junction box


The coordinator junction box is a fuse box which is the link between the coordinator and the rest of the system via a 70-pin connector.

In addition, it has 7 connectors for connecting other items.

### Fuses

The coordinator junction box has 4 fuses.

| Designation | Description   |
|-------------|---|
| F4004       | Miniature circuit breaker of 8 A for U15, located on one of the long sides of the junction box. It prevents engine stop in the event of a short circuit of a lamp or a switch etc. in the instrument panel. |
| F4005       | A 7.5 A fuse for U15 which is installed by the customer inside the junction box. It prevents engine stop in the event of a disruption or short circuit from a customer system.                              |
| F4006       | Fuse of 2 A for U30 to the instruments.   |
| F4007       | Fuse of 2 A for U15 to the instruments.   |



*Coordinator junction box*

339 467





## Connector C4041 for connecting throttle control


Connector for connecting Scania throttle control or equivalent equipment. Use connector 1 507 253, which is supplied with the engine.

| Pin | I/O | Function                     | Pin on co-ordinator. <sup>1</sup> | Comments  |
|-----|-----|------------------------------|-----------------------------------|---|
| 1   | -   | Ground                       |                                   |   |
| 2   | I   | Idling switch                | 30                                |   |
| 3   | -   | Supply to accelerator pedal  | 28                                | The electrical cables should be twisted 40 turns per metre.   |
| 4   | -   | Ground for accelerator pedal | 24                                | May only be connected to pin 24 on the coordinator, not to the battery negative terminal. The electrical cables should be twisted 40 turns per metre. |
| 5   | I   | Accelerator pedal signal     | 54                                | The electrical cables should be twisted 40 turns per metre.   |
| 6   | -   | Ground                       |                                   |   |
| 7   | I   | Kickdown signal              | 34                                |   |

1. The functions on the pins are described in the list of coordinator inputs and outputs for industrial engines.

Use the following tools for connector 1 507 253:

- Hand crimping tool 99 494.
- Dismantling tool 99 581.







## Connector C4029 and C4031 for CAN connection

Diagnostic socket for connecting e.g. SDP3 and CAN communication. Use connector 1 508 055.

### Note:

Any equipment connected to the connector must comply with the CAN specification.


| Pin | I/O | Function | Description   |
|-----|-----|----------|---|
| 1   | O   | U15      | +24 V after fuse F4005 and relay in the junction box. Controlled by the starter lock. |
| 2   | O   | Ground   | Ground  |
| 3   | -   | CAN high |   |
| 4   | -   | CAN low  |   |

Use the following tools for connector 1 508 055:


- Hand crimping tool 99 494.
- Dismantling tool 99 581.

## Connector C4025 for connection to main junction box

Connector for connecting the junction box to the main junction box.



339 205



339 206






## Connector C4030 for connecting instrumentation

Connector for connecting an analogue instrument panel. Use connector 1 725 857.

| Pin | I/O | Function  | Pin on co-ordinator. <sup>1</sup> | Comments  |
|-----|-----|---|-----------------------------------|---|
| 1   | O   | U30   |                                   | Battery voltage.  |
| 2   | O   | U15   |                                   | +24 V after fuse F4004 in the junction box. Controlled by the starter lock. |
| 3   | O   | Ground  |                                   |   |
| 4   | O   | Buzzer  | 5                                 |   |
| 5   | I   | Buzzer off  | 50                                |   |
| 6   | O   | Warning lamp + for SCR malfunction and torque reduction. The signal comes from the engine control unit. | -                                 | Pin 5 on C4002. The pin is not used on marine engines.                      |
| 7   | -   | CAN high  | 45                                |   |
| 8   | -   | CAN low   | 21                                |   |
| 9   | -   | Not used  |                                   |   |
| 10  | -   | Not used  |                                   |   |
| 11  | O   | Warning lamp + for low reductant level. The signal comes from the engine control unit                   | -                                 | Pin 3 on C4002. The pin is not used on marine engines.                      |
| 12  | O   | Warning lamp - for low reductant level. The signal comes from the engine control unit.                  | -                                 | Pin 4 on C4002. The pin is not used on marine engines.                      |







| Pin | I/O | Function   | Pin on co-ordinator. <sup>1</sup> | Comments   |
|-----|-----|--|-----------------------------------|--|
| 13  | I   | Lamp test  | 9                                 |  |
| 14  | O   | Warning lamp - for SCR malfunction and torque reduction, the signal comes from the engine control unit | -                                 | Pin 6 on C4002. The pin is not used on marine engines. |

1. The functions on the pins are described in the list of coordinator inputs and outputs for industrial engines.

Use the following tools for connector 1 725 857:

- Hand crimping tool 99 491.
- Dismantling tool 99 582.





## Connector C4026 for connecting control panel


Connector for the Scania control panel or equivalent equipment. Use connector 1 505 531.



### IMPORTANT!

When connecting to connector C4026, a resistor should be connected between pin 10 and 11, otherwise a fault code is generated.

| Pin | I/O | Function               | Pin on co-ordinator. <sup>1</sup> | Comments  |
|-----|-----|------------------------|-----------------------------------|---|
| 1   | O   | U30                    |                                   | Battery voltage.  |
| 2   | I   | U15                    |                                   | +24 V after the starter lock, not fused.  |
| 3   |     | Not used               |                                   |   |
| 4   | O   | Ground                 |                                   |   |
| 5   | I   | Engine start (U50)     | 32                                |   |
| 6-9 | -   | Not used               |                                   |   |
| 10  | I   | Adjust 1               | 29                                | A fault code is generated if the pins are not used. A resistor should be connected between pin 10 and 11. |
| 11  | I   | Adjust 2               | 48                                |   |
| 12  | I   | Engine speed setting 1 | 13                                |   |
| 13  | I   | Engine speed setting 2 | 36                                |   |
| 14  |     | Not used               |                                   |   |
| 15  | I   | Engine shutdown        | 51                                |   |







| Pin   | I/O | Function | Pin on co-ordinator. <sup>1</sup> | Comments |
|-------|-----|----------|-----------------------------------|----------|
| 16-24 | -   | Not used |                                   |          |

1. The functions on the pins are described in the list of coordinator inputs and outputs for industrial engines.

Use the following tools for connector 1 505 531:

- Hand crimping tool 99 491.
- Dismantling tool 99 582.





## Connector C4032 for connecting extra functions


Connector for connecting extra functions. Use connector 1 725 857.

| Pin  | I/O | Function                    | Pin on co-ordinator. <sup>1</sup> | Comments  |
|------|-----|-----------------------------|-----------------------------------|---|
| 1    | O   | Ground                      |                                   |   |
| 2    | I   | Engine speed setting 1      | 13                                | See section Engine speed setting 1 and 2.                           |
| 3    | I   | Engine speed setting 2      | 36                                |   |
| 4    | I   | Low idle speed adjustment 1 | 52                                | Should be connected to ground, otherwise a fault code is generated. |
| 5    | I   | Low idle speed adjustment 2 | 53                                | Not connected.  |
| 6    | I   | Torque limit switch 1       | 60                                |   |
| 7    | I   | Torque limit switch 2       | 40                                |   |
| 8-10 | -   | Not used                    |                                   |   |
| 11   | I   | Disengaging engine shutdown | 57                                |   |
| 12   | I   | Exhaust brake               | 46                                |   |
| 13   | I   | Cruise control off          | 8                                 |   |
| 14   | O   | U30                         |                                   | Battery voltage. Fused with 7.5 A.                                  |

1. The functions on the pins are described in the list of coordinator inputs and outputs for industrial engines.

Use the following tools for connector 1 725 857:

- Hand crimping tool 99 491.
- Dismantling tool 99 582.



339 209





## Base system for marine engines


### Note:

The following pages list the connectors on the main junction box and the coordinator junction box which are unique to the base system for marine engines. Other connectors are described in the Base system for industrial engines section.

The base system is easy to connect without any major adaptations.

It can be supplemented with an accelerator pedal sensor, analogue instrument panel, control panel with key switch, remote control and digital display. All these accessories are connected and are ready for immediate use.

Other units can also be connected via the CAN network.




*Base system for marine engines*

- 1. Engine control unit*
- 2. Main junction box*
- 3. Coordinator junction box*
- 4. Coordinator*





A base system for marine engines is shown here with Scania units connected.



*Base system for marine engines with Scania units connected*

- 1. Engine control unit*
- 2. Main junction box*
- 3. Remote control*
- 4. Connection cable: 2, 8, 12 or 24 m*
- 5. Coordinator junction box*
- 6. Extension cable: 2 or 8 m*
- 7. Accelerator pedal sensor*
- 8. Extension cable: 2 m*
- 9. Scania digital display*
- 10. Coordinator*
- 11. Control panel*
- 12. Analogue instrument panel*





## Connection to main junction box


The main junction box is located between the engine control unit on the engine and the rest of the system.

It has five connectors for connecting other items to the external electrical system. One of the connectors is unique for the base system for marine engines – C4404. The other four connectors are described under the heading Connection to main junction box in the Base system for industrial engines section.

## Fuses

The main junction box has 4 fuses. They are positioned next to each other along one of the long sides of the junction block.

| Designation | Description   |
|-------------|---|
| F4001       | Miniature circuit breaker of 20 A for U30 to the engine control unit. |
| F4003       | Miniature circuit breaker of 8 A for U30 to the instruments.          |
| F4008       | Miniature circuit breaker of 20 A for U31 to the engine control unit. |
| F4009       | Miniature circuit breaker of 8 A for U31 to the instruments.          |



*Main junction box*

339 218






## Connector C4044 for connecting remote control

Connector for connecting a remote control. Use connector 1 507 253, which is supplied with the engine.

| Pin | I/O | Function              | Description  | Comments   |
|-----|-----|-----------------------|--|--|
| 1   | I   | Remote control lock 1 | Blocks operation from positions other than the remote control. | When the pin is connected to ground, the engine cannot be run from the normal position.  |
| 2   | I   | Remote control lock 2 | Blocks operation from positions other than the remote control. | When the pin is connected to ground, the engine cannot be run from the normal position.  |
| 3   | I   | Engine start (U50)    | Starts the engine.   | When the pin is connected to +24 V, the starter motor runs and the engine only runs at idling.   |
| 4   | -   | +24 V (U30)           | Power supply to the remote control.                            | Direct supply from the battery. Fuse, 20 A.  |
| 5   | -   | Ground                | Ground for the remote control.                                 |  |
| 6   | I   | Engine shutdown       | Shutting down the engine.                                      | To stop the engine, the pin should be connected to ground. The engine can also be shut down via the starter lock by disconnecting U15. |
| 7   | O   | Indicator lamp        | +24 V when the remote control lock is activated.               | The signal from S6 indicates that this position is active.   |

Use the following tools for connector 1 507 253:



339 212





- Hand crimping tool 99 494.
- Dismantling tool 99 581.





## Connection to coordinator junction box

The coordinator junction box is a fuse box which is the link between the coordinator and the rest of the system via a 70-pin connector.

In addition, it has 7 connectors for connecting other items. One of the connectors is unique for the base system for marine engines – C4045. The other six connectors are described under the heading Connection to junction box in the Base system for industrial engines section. The four fuses of the junction box are also described there.

## Connector C4045 for connecting extra functions


Connector for connecting extra functions. Use connector 1 508 055.

| Pin | I/O | Function                    | Pin on coordinator. <sup>1</sup> |
|-----|-----|-----------------------------|----------------------------------|
| 1   | I   | Disengaging engine shutdown | 57                               |
| 2   | -   | Ground                      |                                  |
| 3   | I   | Torque limit switch 2       | 40                               |
| 4   | I   | Torque limit switch 1       | 60                               |


1. The functions on the pins are described in the list of Coordinator inputs and outputs for marine engines.

Use the following tools for connector 1 508 055:

- Hand crimping tool 99 494.
- Dismantling tool 99 581.



Coordinator junction box



339 219

339 213





## Extra functions

### Industrial and marine engines

#### Throttle control

There are three alternative ways to increase engine speed.

1. With Scania throttle control which is connected to the coordinator junction box.
2. With your own throttle control via the CAN network if this has been ordered.
3. With your own analogue throttle control which is connected to the junction box.

#### Engine speed adjustment

There are three ways of changing the set idling speed on an engine:

1. Using Scania's control panel.
2. Using the Scania digital display.
3. Using SDP3.





## Torque limitation

For industrial engines, torque limitation is routed to pin 6 and 7 on the junction box connector C4032. For marine engines, torque limitation is routed to pin 3 and 4 on the junction box connector C4045.

Using this function, it is possible to choose which power curve the engine should follow. Most engine types only have one standard curve: maximum engine torque. Some engine types also have a lower standard curve.

For S8 it is possible to program one customised power curve using SDP3. For S6 it is possible to program two customised power curves using SDP3. These curves can be selected by activating torque limit switches 1 and 2 in different combinations according to the table. The two customised power curves can only be set lower than the standard curve.

| <b>Torque limit switch 1 - pin 60 on coordinator</b> | <b>Torque limit switch 2 - pin 40 on coordinator</b> | <b>Curve</b>   |
|--|--|--|
| Not connected  | Not connected  | "0", maximum engine torque   |
| Ground   | Not connected  | "1", maximum engine torque/other and lower engine torque requested |
| Not connected  | Ground   | "2", customised, engine control unit S6                            |
| Ground   | Ground   | "3", customised, engine control unit S6 and S8                     |





## Industrial engines only

### Engine speed setting 1 and 2

Engine speed setting 1 and 2 are routed to pin 2 and 3 on the junction box connector C4032.

The function can be used to control the engine speed in different ways, e.g. setting a fixed engine speed. Using the setting buttons on the control panel, the engine speed can be changed between low and high idling.

The engine speed can also be changed and saved using the functions Adjust 1 and Adjust 2 on pin 10 and 11 in connector C4026.

The following functions are available:

| Function                  | Engine speed setting 1 | Engine speed setting 2 |
|---------------------------|------------------------|------------------------|
| Normal hand throttle      | -                      | -                      |
| Limited hand throttle     | Ground                 | -                      |
| Fixed raised idling speed | -                      | Ground                 |
| Fixed engine speed        | Ground                 | Ground                 |

Engine speed setting 1 and 2 can be used together with power take-off operation.

### Normal hand throttle

Maximum engine speed and maximum engine torque can be set using SDP3. It is also possible to set maximum engine torque using the Scania digital display.





It is also possible to change the engine speed between low and high idling using the functions Adjust 1 and 2 in connector C4026. The functions are described at pin 29 in the list for the industrial engine coordinator. The following can be done:

- **Activate:** Activates the functions.
- **Deactivate:** Switches off the functions.
- **Increase:** Increases the engine speed. A short signal increases the engine speed by 20 rpm while a signal longer than 0.5 s increases the engine speed until the signal stops.
- **Decrease:** Decreases the engine speed. A short signal decreases the engine speed by 20 rpm while a signal longer than 0.5 s decreases the engine speed until the signal stops.
- **Save:** Saves the current engine speed if the signal is at least 3 s; a short signal makes the engine speed return to the last saved value.

The function can be deactivated in two ways:

1. Via Activate using Adjust 1 and 2.
2. Activate Cruise control off: C4032 pin 13 to +24 V.

### Limited hand throttle

Limited hand throttle functions in the same way as Normal hand throttle. It is also possible to set if it should be possible to overspeed using the accelerator pedal or not with SDP3.

The function can be deactivated in three ways:

1. Disconnect ground from pins 2 and 3 in connector C4032.
2. Connect pin 13 in connector C4032 to +24 V.
3. Connect pin 5 in connector C4030 to ground.





## Fixed raised idling speed

The function is used to temporarily increase the idling speed. The idling speed can be set and saved between 450 and 800 rpm.

The idling speed is changed and saved using the buttons, to increase (UP), decrease (DOWN) and save (STORE) on the Scania control panel.

The function can only be deactivated by disconnecting ground from pins 2 and 3 in connector C4032.

## Fixed engine speed

If a fixed engine speed has been set in the engine control unit using SDP3, it can be used here. The set value cannot be changed using the setting buttons on the control panel nor can it be changed with the accelerator pedal.

The function can be deactivated in three ways:

1. Disconnect ground from pins 2 and 3 in connector C4032.
2. C4032 pin 13 to +24 V.
3. C4030 pin 5 to ground.